

symbol	color	description
12V	RED	+12 V
GND	BLACK	-12 V
CH2	GREEN	IMPULSE

0,5€- 1 impulse
1€- 2 impulses
2€- 4 impulses

Settings on electronics for EURO

Coin impulse = 0,50 (**0,5€= 1 impulse**)

Start impulse =4 (Game for 2€ = 4 impulses)

Start-impulse - After how many impulses there is one game

Menu Motherboard JB5							Comments
1	Coin/impulse	0,5					the smallest coin
2	Start-Impulse	2	<1 "free-play"				after how many coins the device starts
3	Game time	00m25s					Game time
4	Activate Bonus	active					Active Bonus
		inactive					Inactive Bonus
5	Set bonus	Imp4. Bon. 1	Imp1. Bon.0	Imp1. Bon.0	Back to menu		Set Bonus
6	Demo	volume	100				Demo volume
		Repeat time	600s				Repeat Demo
		Back to menu					
7	Hit point	1					how many points for one hit
8	Sub. Game pts.	1					How many points are subtracted for a bad hit (in red)
9	Pad change	3s					After what time of inactivity the active pads change
10	Tickets	Active	Point/ticket	Highscore/ticket	Highscore/credit	Substract point	Back to menu
		Inactive	100	1	1	1	
							Ticket setting
11	Clear counts	Clear Points	Clr. Money amount	Clr.ticket count	Back to menu		
		Cancel	Cancel	Cancel			
		Clear	Clear	Clear			Counts
12	Change code	Write New Code					
		0***					Change code
13	Language	English					Language
14	Serial no.	sn_____					Serial number
15	Update	cancel/ download					software update
16.	Exit						Exit (acceptance of introduced changes)